


## VOLTMETER

Model # GIVM, GIVM24, GIIVM - All Colors  
Installation Instructions

### WIRING:

1. Remove battery cable.
2. This Voltmeter requires 2 1/6" diameter hole in the instrument panel.
3. Meter can be connected as follows:
  - A. Connect the NEG. GND to G.
  - B. Connect the IGNITION VOLTAGE to I.
  - C. Connect the LIGHT SWITCH to TERMINAL



4. Reconnect battery ground. If meter does not read up scale, reverse meter leads.

# VOLTMETER

## Trouble Shooting

**STEP ONE (this usually solves the problem)** - Before you do anything else check for defective wiring or grounds, as this is the most common cause of failures. Inspect all wiring at terminals. Also, look for corroded or missing engine ground strap connections.

**STEP TWO** - If pointer in receiver does not move when ignition switch is turned on, check to see that current is actually being carried from the ignition switch to the terminal "I" on the receiver. Also, check to see that paint or corrosion does not prevent proper ground. If pointer still does not move, receiver is defective and must be replaced.

**STEP THREE** - If receiver meter is not accurate with sender, check the receiver to be sure it is the correct OHM and VOLTAGE.

<b>QUICK- CHECK TROUBLE LOCATOR</b>	
NO INDICATION AT FAR RIGHT	<ol style="list-style-type: none"><li>1. No current to ignition terminal because of broken or disconnected lead.</li><li>2. Grounded wire between sender and receiver.</li><li>3. Receiver not grounded.</li><li>4. Sender defective.</li></ol>
EXCESSIVE POINTER FLUCTUATION	<ol style="list-style-type: none"><li>1. Loose wire connections.</li><li>2. Defective sender</li></ol>
LOW READING AT ALL TIMES	<ol style="list-style-type: none"><li>1. Wire to sender broken.</li><li>2. Sender not properly grounded.</li><li>3. Defective sender.</li></ol>
INDICATES IN ACCURATELY	<ol style="list-style-type: none"><li>1. Incorrect sender.</li><li>2. Low voltage at receiver terminals.</li><li>3. Defective sender.</li></ol>
POINTER FLUCTUATES WHEN LIGHTS ARE TURNED ON	<ol style="list-style-type: none"><li>1. Engine not properly grounded.</li></ol>