



*The #1 Choice in  
Performance Boating!*

## INSTALLING LIVORSI® CAPACITIVE SENDER WITH THE SMARTCRAFT™ SYSTEM

1. THE SENDER HAS A STANDARD 5 HOLE BOLT PATTERN.
2. THE SENDER HAS A 3 TERMINALS TO BE CONNECTED.
3. THE TERMINAL MARKED "SEND" IS TO BE CONNECTED TO THE PINK/BLACK WIRE IN THE MERCURY HARNESS.
4. THE TERMINAL MARKED "POS" IS TO BE CONNECTED TO THE USUAL IGNITION SWITCH. **DO NOT CONNECT TO BATTERY.**
5. THE TERMINAL MARKED "NEG" IS TO BE CONNECTED TO THE BLACK/ORANGE WIRE ON THE MERCURY HARNESS. THIS WIRE **DOES NOT** GO TO "BOAT" GROUND. IT **SHOULD NOT** BE GROUNDED TO THE TANK.