



DUAL TRIM SWITCH

Installation Instructions



NOTE:

Due to the gauge of the Dual Trim Switch wires,
a relay must be used to connect to the trim pump.