



## Low Lux Night Vision Camera Model # CNVLLW

### Instructions

- Connect 20 ft dual video / power cable to back of the camera, the connection is threaded and a twist lock.
- Mount the camera to an unobstructed navigating position on your vessel.
- Connect video connection to standard monitor
- Connect 12 Volt DC+ connection (cigarette adapter) to 12 Volt DC+ power. If cigarette adapter is not used, we strongly recommend the hiring of a professional installer.
- **The Low Lux Night Vision Camera should only be operated with DC positive power input only!!**
- **Using a DC negative power input will damage the camera and void all warranties.**
- Once connections have been made, turn on DC+ power and monitor, the night vision camera should work perfectly.

**Focusing-** All focusing of the camera should be done at night for best results.

If the camera is out of focus please follow the following instructions:

- Open Camera by unscrewing the front housing counter clockwise
- Adjust focus on lens by losing the tightening screw on the lens.
- Adjust focus on the lens, retighten the tightening screw.
- **Do not adjust aperture screw or aperture adjustment.**
- Close the camera by screwing on the front housing.....**Hand Tight.**
- There should be no gaps in the camera housing joint when hand tightening is completed.

### Warnings

- The night vision camera requires an input voltage of 12 Volt DC positive. **Any negative voltage input will damage the camera and void all warranties.**
- Please take all safety precautions while installing the camera electrical connects.
- **These products should not be used as a sole navigation device. These products are not a substitution for standard marine safety guidelines and common sense.**
- The Low Lux Night Vision Camera is water resistant but not designed to be submerged underwater.

### Warranty

Housing - 3 Years

This Limited Warranty is void if Livorsi Marine, Inc. suspects any tampering of internal components of the See Cannon Series which includes but not limited to, opening the housing. This warranty covers all workmanship. No abuse of materials is covered with this Limited Warranty.