

## • Vantage View® Implementation of SmartCraft® Parameters

Parameter Name	Parameter Name
Diesel MS Boost Pressure	Gas/Diesel LS Sea Water Temperature
Diesel MS Load Percent	Gas/Diesel MS Boat Speed (Paddle Wheel)
Gas MS Actual Gear	Gas/Diesel MS Engine RPM
Gas MS Fault: Water Pressure	Gas/Diesel MS Fault: CAN
Gas MS Manifold Pressure	Gas/Diesel MS Fault: Check Engine/Guardian
Gas MS Manifold Vacuum	Gas/Diesel MS Fault: Coolant Temperature
Gas MS Trim Position	Gas/Diesel MS Fault: Oil
Gas MS Warn: Guardian Active	Gas/Diesel MS Fault: Voltage
Gas MS Warn: Low Block Pressure	Gas/Diesel MS Fault: Water In Fuel
Gas MS Warn: Low Drive Lube	Gas/Diesel MS Fuel Flow Total
Gas MS Warn: Low Oil Remote	Gas/Diesel MS Fuel Pressure
Gas MS Warn: Low Oil Reserve	Gas/Diesel MS Steering Angle
Gas/Diesel LS Accumulated Break-in Time	Gas/Diesel MS Throttle Position
Gas/Diesel LS Airmar Data Status	Gas/Diesel MS Warn: Check Engine
Gas/Diesel LS Airmar Depth	Gas/Diesel MS Warn: High Voltage
Gas/Diesel LS Airmar Optional Temperature	Gas/Diesel MS Warn: Low Oil Pressure
Gas/Diesel LS Airmar Sea Water Temperature	Gas/Diesel MS Warn: Low Voltage
Gas/Diesel LS Barometric Pressure	Gas/Diesel MS Warn: Over Speed
Gas/Diesel LS Battery Voltage	Gas/Diesel MS Warn: Over-Heat
Gas/Diesel LS Block/Water Pressure	Gas/Diesel MS Warn: Water in Fuel
Gas/Diesel LS Boat Speed ( Airmar Data)	Gas/MS Boat Speed (Low/High Press Pitot)
Gas/Diesel LS Break-in Time Required	
Gas/Diesel LS Coolant Temperature	
Gas/Diesel LS Engine Type	
Gas/Diesel LS Exhaust Temperature	
Gas/Diesel LS Fuel Level 1	
Gas/Diesel LS Fuel Level 2	
Gas/Diesel LS Gear Pressure	
Gas/Diesel LS Gear Temperature	
Gas/Diesel LS Intake Manifold Temperature	
Gas/Diesel LS Oil Level	
Gas/Diesel LS Oil Pressure	
Gas/Diesel LS Oil Temperature	
Gas/Diesel LS Oil Time & Complete	
Gas/Diesel LS Port Coolant Temperature	
Gas/Diesel LS Reserve Oil Remaining	
Gas/Diesel LS Run Time	