



## Trim Calibration (CAN Bus Input)

NOTE: When calibrating Full Up & Full Down, the boat is to be in the water. This will result in the most accurate calibration for normal operating positions.

DO NOT set Full Up in trailer position.

### 1. Calibration

- a. Press & Hold Mode Button to gain access to the Main Menu
- a. Scroll down to Setup & press Mode button to gain access to Setup Menu
- b. Scroll down to Calibration and press Mode button
- c. Scroll down to Engine Trim and press Mode button
- d. Select Source from Engine Trim menu (Press Mode button)
- e. Scroll down to CAN Bus and press Mode button
- f. Scroll down to Full Down and press Mode button
- g. Move the Engine Trim to the Down position
- h. Press the up button, select the "Set XX%" value and press Mode button to accept
- i. Scroll down to the Full Up and press Mode button
- j. Move the Engine Trim to the Up position
- k. Press the up button, select the "Set XX%" value and press Mode button to accept
- l. Scroll down to the Save and press Mode button
- m. Scroll up to Yes and press Mode button